

Steel Floor Sleeve Application

27" High Guardrail
and Higher



Using a Core Bit 10", Core
Hole into Depth of Cement.



Drop in 5" X 5" Square Steel
Floor Sleeve and Fill in
Around Sleeve and Cement



Guide Leg Into Core



Your Guardrail is now
Installed!



...Easy Installation...

Easy to install and remove

Bolt-In Installation

Applicable for all guardrail heights!



Align Rail as Required



Using a Core Bit 3/4", Drill Holes
in Surface with Hammer Drill



Secure Base Plate with
3/4" x 6 1/4" Anchors



Your Guardrail is Now
Installed

Core-In Application

27" High Guardrail
and Lower



Using a Core Bit 5 1/8",
Core Hole into Depth
of Cement.



Using Fork Lift, or Two Man
Team, Place Guardrail
above Core



Guide Leg into Core.



Your Guardrail is now
Installed!

