



Work Instructions for Cutting Down AisleCop Gate Arms

Tools needed

1. Measuring tape
2. Scissors
3. Chop Saw

Objective: Subtracting length on an AisleCop Gate arm (If Needed).

Cutting will be done from the top of the arm. Do Not cut the bottom of the arms where the bolt holes are located.

1. Remove Protective Foam from arm (slide foam back)



2. From the top of the arm, measure length that is to be subtracted to reach your desirable length, and mark. Example for an 8ft arm. Subtract 4ft. ($12\text{ft} - 4\text{ft} = 8\text{ft}.$) (Top of the arm is the opposite end with the mounting holes.)



3. Using a Chop (cutting) Saw cut off to desired length.



1. On the LED strips, locate copper markings. At the closest marking under the desirable length, cut LED strips on the marking.



2. Re-install Protective Foam.