



by



T-REX A/C Cage Instructions

- Step # 1.** Attach Front Right Post to Side Panel 1 with 2 tek screws
- Step # 2.** Then attach Back Right Post to the previous Side Panel 1 with 2 tek screws
- Step # 3.** Slide in anti-separation bar into designated slots at the top of the post to go over the top of the panel
- Step # 4.** Attach Front Panel (panel with lock hasp) to previous Front Right Post (*lock hasp must be facing out*)
- Step # 5.** Connect Front Left Post to Front Panel with 2tek screws
- Step # 6.** Slide in anti-separation bar into designate slots at the top of the post to go over the top of the panel
- Step # 7.** Attach Front Left Post to Side Panel 2 with 2 tek screws
- Step # 8.** Then attach Back Left Post to Side Panel 2 with 2 tek screws
- Step # 9.** Slide in anti-separation bar into designated slots at the top of the post to over the top of the panel
- Step # 10.** Then place the anti-separation bar into designated slots to connect the two back Post
- Step # 11.** Slide Top Panel horizontally into Post channels (*top hasp must align with Front Panel lock hasp*)
- Step # 12.** Install Puck Lock
- Step # 13. Extended Post Installation:** Dig holes to the appropriate level of depth and add concrete to secure the post

OR

Plated Post Installation: Connect plated post to concrete with wedge anchors