# ASSEMBLY SEQUENCE STEP 1 ASSEMBLE OPEN UPRIGHTS 5/16-18 X 5/8" **BOLT** 34-1/2" 5/16-18 HEX\_ WAFFLE NUT VERTICAL DISTANCE VERTICAL VERTICAL DISTANCE VERTICAL SHELF **DEPTH DISTANCE** 12" 12" 15" 15" 18' 18" 42" 24" 24' 34-1/2" 30' 30' 36" 36' 84" AND 96" **UPRIGHTS** 120" UPRIGHTS

# IN NEED OF ASSEMBLY ASSISTANCE?

Contact us direct for fast friendly service (800) 433-8488 Int'l calls (630) 892-8941 | WEB: WWW.LYONWORKSPACE.COM | Fax (800) 367-6681

ASSEMBLY INSTRUCTIONS LYON SINGLE LEVEL 8000 SERIES OPEN SHELVING



**9307DA**SHEET 1 OF 3

### ASSEMBLY SEQUENCE

IN BACK TO

ARE PLACED

BACK BRACE.

SHOULD BE

**ALTERNATED** 


AND END TIE

**BE USED** 


ALL END

**THIRD** 


# STEP 2 **ASSEMBLE SHELF CLIPS TO POSTS CLIPS INTERMEDIATE UPRIGHT** END **UPRIGHT**



STEP 4 **BOLT BACK SWAY BRACE TO REAR POSTS. BACK** TO BACK SECTIONS WILL SHARE A BRACE.



STEP 4A ASSEMBLY USED FOR BACK TO BACK **SECTIONS ONLY** 



## IN NEED OF

### ASSEMBLY ASSISTANCE?

Contact us direct for fast friendly service (800) 433-8488 Int'l calls (630) 892-8941 | WEB: WWW.LYONWORKSPACE.COM | Fax (800) 367-6681


ASSEMBLY INSTRUCTIONS FOR LYON SINGLE LEVEL 8000 SERIES OPEN **SHELVING** 




9307DA SHEET 2 OF 3


### ASSEMBLY SEQUENCE

# END TIE CLIP ASSEMBLY ONLY FOR BACK TO BACK SECTIONS 2 END TIE CLIPS USED EVERY THIRD UPRIGHT IN BACK TO BACK SECTIONS. LOCATE CLIP WITHIN 18" FROM TOP AND BOTTOM OF POST. SECURE END TIE CLIP WITH TWO 5/16" X 3/4" HEX HEAD BOLTS AND 5/16" NUTS. TWO HIGH APPLICATIONS WILL USE (4) END TIE CLIPS OVER TWO LEVEL ELEVATION. 5/16" OP10285





<sup>∠</sup>FOOTPLATE



### IN NEED OF

### ASSEMBLY ASSISTANCE?

Contact us direct for fast friendly service (800) 433-8488 Int'l calls (630) 892-8941 | WEB: WWW.LYONWORKSPACE.COM | Fax (800) 367-6681

ASSEMBLY INSTRUCTIONS FOR LYON SINGLE LEVEL 8000 SERIES OPEN SHELVING



**9307DA**SHEET 3 OF 3