

# ASSEMBLY INSTRUCTIONS

## 52505 | Drying Rack Frame



**Do NOT use a hammer.** Shelf damage may occur voiding any and all guarantees.

1. Lay top frame at a right angle to the floor and position the first post on the top frame (usually the very top) and tighten the set screw using the provided Allen wrench.

*Note: The set screws are already in the shelf collar.*

### **Before Inserting Any Poles:**

Check and back out any set screws that may be too far inset (to prevent loss during shipping).



2. Position the second and remaining frame on the first post (**Figure A**). Use the locator rings to accurately obtain the desired spacing.

*Note: The locator rings are on 2" centers*

3. Tighten the set screws — see above.
4. Insert pole #2 through the opposite corners. (**Figure B**)
5. Align the frames again using the locator rings. (**Figure C**)

*Note: After tightening the top frame, the remaining frames will need only minimal adjustment to find the corresponding locator ring.*

6. Insert the remaining posts (**Figure D**). Align frames and posts to correspond with the first post alignment.

Tighten all set screws.

*Note: In order for unit to be NSF Certified, plastic inserts (provided), must be placed in set screws after tightening.*



### **Leg Leveling Feet Are Unnecessary!**

To level your new unit, simply place it in its permanent position. Check to see that all posts set firmly on the floor. If a corner is high, simply loosen the set screws on that post only, let the post slide to the floor and retighten.

**Locator Rings Make Assembly Quick and Easy**

*All you need is a  $\frac{3}{16}$ " Allen wrench.*



**Figure A**



**Figure B**



**Figure C**



**Figure D**

**NEWAGE  
INDUSTRIAL  
NEWAGE**

NewAgeIndustrial.com || 800-255-0104