




AIR PEAR MOUNTING GUIDELINES



FOR BEST EFFICIENCY the Air Pear Thermal Equalizer should be securely installed as close as possible to the ceiling. The Air Pear air column should have an unobstructed passage to the floor. The Air Pear should not be mounted directly in front of heat ducts, vents or near any high heat source.