



# MAST ALERT



Ultrasonic Sensor



Digital readout; mounts on dash



- **Eliminates guesswork**
- **Protects high bay inventory**
- **Helps with stacking**



Mast ALERT measures the position of the mast and indicates to the operator when forks are level.