


LO-J-BEAM



Ref. #	Model #	Generic Part #	Eng. Part #	Description
1	LO-J-BEAM	LOMB-HGP	13-025-003	Handle Grip
7	LO-J-BEAM	LOBM-BAL-A	01-145-013	Steel Ball
8	LO-J-BEAM	LOBM-SPR	13-146-003	Spring
9	LO-J-BEAM	LOBM-BOLT-1	11209	Bolt
10	LO-J-BEAM	LOBM-WHLAX	13-612-001-1/2	Wheel Axle 1/2" Diam. For 8" Wheels
	LO-J-BEAM	LOBM-10-WHLAX-1/2		Wheel Axle 1/2" Diam. For 10" Wheels
	LO-J-BEAM	LOBM-10-WHLAX-5/8		Wheel Axle 5/8" Diam. For 10" Wheels
11	LO-J-BEAM	LOBM-WHREAR	16-132-033-1/2	Semi Pneumatic 8" Wheel With 1/2 " Bearing
	LO-J-BEAM	LOBM-10-WHL-1/2		Semi Pneumatic 10" Wheel With 1/2" Bearing
	LO-J-BEAM	LOBM-10-WHL-5/8		Semi Pneumatic 10" Wheel With 5/8" Bearing
12	LO-J-BEAM	LOBM-CTRPN	65078	Cotter Pin
13	LO-J-BEAM	LOBM-BOLT-2	11064	Wheel Bolt
15	LO-J-BEAM	LOBM-WHFRNT	16-132-007	Steel 4" Wheel
16	LO-J-BEAM	LOBM-SPLWSR	33620	Lock Washer
17	LO-J-BEAM	LOBM-HXNUT	36104	Nut
18	LO-J-BEAM	LOBM-TADJSFT	13-154-007	Tension Adjustment Shaft
	LO-J-BEAM	LOBM-KITA-1/2	13-154-008-1/2	Rear Wheel Kit 8" Wheels With 1/2" Axle
	LO-J-BEAM	LOBM-KITA-B-1/2		Rear Wheel Kit 10" Wheels With 1/2" Axle
	LO-J-BEAM	LOBM-KITA-B-5/8		Rear Wheel Kit 10" Wheels With 5/8" Axle
	LO-J-BEAM	LOBM-KITB	13-154-009	Front Wheel Kit Includes 13-17
	LO-J-BEAM	LOBM-KITC	13-145-001	Jack Head

