

Replacement Strips Installation Guide

1. Remove strips to be replaced
2. Insert interlocking screws into pre-punched holes (A)
3. Slide strips into mounting bar (B)

