

# MAINTENANCE GUIDE

## GENIEGRIPS® STIK-IT PADS

### STEP 1:

#### Raise Tines to Waist

SAFELY raise fork tines to waist height.



### STEP 2:

#### Clean Surface

Using warm soapy solution, remove any grease, oil, paint, ice, grit, etc...



### STEP 3:

#### Dry Surface

Using dry cloth, remove any moisture or residue



### Check for Wear & Tear

However, if your GenieGrips® Stik-It Pads have excessive tearing and damage to the rubber as in the images below, replace with a new Pad or please contact your GenieGrips representative to order replacement units.



### Removal of Pads

Once the Pads have started to come away from the tine, it is time to replace the Pad.

Peel the Pad from the tine and go to Step 1 of installation instructions, How To Fit GenieGrips® Stik-It Pads.



Distributed by Cisco-Eagle, Inc.  
[www.cisco-eagle.com](http://www.cisco-eagle.com)  
888-877-3861