


CRANK-OUT CANTILEVER


SIDE VIEWS & DIMENSION OPTIONS

FRONT VIEWS & DIMENSION OPTIONS


Spacings for Standard Stock Lengths*




(2) UPRIGHT UNIT




(2) UPRIGHT UNIT




(3) UPRIGHT UNIT



20" DEEP ARM



24" DEEP ARM





36" DEEP ARM

ACCESSORIES

Stock Divider

Used to separate various types of stock on the crank-out cantilever arm.



Intermediate Support

Used to store various lengths of stock too short or too weak for standard upright spacing.