


Installations Instructions





Included with your order:

- 1) Two outdoor sensors
- 2) One powder coated stainless steel Look Out 1 exterior unit
- 3) One control box
- 4) One power cord
- 1) Mount each exterior sensor. NOTE: the exterior sensor bracket may be taken apart by loosening up the plastic wing nut and then re-attaching after mounting to the wall.
- 2) Mount the Look Out exterior at the corner of the building.
- 3) Drill holes in the wall and push through the wires which will connect to the control box.
- 4) Open the control box and mount the rear portion.
- 5) Feed sensor wires into the top of the unit as indicated on the front page illustration.
- 6) Connect sensor wires according to color.
- 7) Put front cover back on.
- 8) Plug in the lead wires from the exterior box.
- 9) Plug in power.
- 10) Verify that the opposite light flashes when the sensor is activated.
- 11) Customer Service = 877-728-3891