
IQ plus® 355 Digital Weight Indicator Panel Mount Option

PN 52948

Use the following procedure to install the panel mount option:

- 1. Use the cutout template to make a 9.8" W x 6.3" H (249 mm W x 160 mm H) cutout in the panel. Ensure cutout is far enough from panel edge to accommodate bezel: panel mount bezel dimensions are 10.5" W x 7.0" H (267 mm W x 178 mm H).
- 2. If attached, remove the tilt stand from the indicator enclosure.
- 3. Peel adhesive backing from the bezel gaskets, then press bezel into the panel cutout.
- 4. Insert the indicator into the panel mount bezel from the rear. Align holes in side of indicator enclosure with holes in the bezel flange.
- 5. Use the 1/4-20 x 1/2" cap screws and lock washers provided to attach the L-brackets to the outside of the installed bezel and indicator.
- 6. Start the four 1/4-20NC x 1 3/4" round-head machine screws into the panel mount brackets. Place a



NOTE: The IQ plus 355 panel mount bezel gasket

12 requirements for dust-proof

meets NEMA

Figure 1. IQ plus 355 Panel Mount Kit Components

few drops of a removable-strength thread adhesive (such as Loctite[®]) on the screw threads to prevent loosening in high-vibration environments. Tighten screws until the indicator is held securely against the panel. Figure 2 shows a top view of a completed panel mount installation.




Figure 2. Panel Mounted IQ plus 355 (Top View)

See the IQ plus 355 Installation Manual, PN 51980, for more information about installation procedures and requirements.

