

# HOW TO FIT GENIEGRIPS® MATS



## STEP 1:

### Raise Tyne to Waist

SAFELY raise forktynes to waist height.



## STEP 2:

### Insert Heel

Slide heel hook onto the forktyn.



## STEP 3:

### Guide Toe Cap

Guide toe cap onto the front tip of the forktyn.



## STEP 4:

### Slide Heel Hook

Finish by sliding the heel hook behind the heel of the forktyn.



## STEP 5:

### To Remove

Reverse steps 1-4 to remove GenieGrips.



## STEP 6:

### Storage

Fold Mats in half and store away neatly on forklift to ensure GenieGrips are easily accessible at all times.



## ALWAYS:

- Ensure forklift truck is only operated by licensed/trained personnel and in accordance with manufacturer's safe operating procedures.

## HELPFUL HINT:

*"The installation/removal of GenieGrips® Mats should take no more than 30 seconds, if there is resistance when installing/removing please contact your GenieGrips® representative."*