

MAINTENANCE GUIDE

GENIEGRIPS® MATS



STEP 1:

Raise Tynes to Waist

SAFELY raise forktynes to waist height.



STEP 2:

Clean Surface

Using warm soapy solution, remove any grease, oil, paint, ice, grit, etc...



STEP 3:

Dry Surface

Using dry cloth remove any moisture or residue.



STEP 4:

Check for Wear & Tear

Over time and general use, you may lose fragments of rubber from the Mats – in particular near the tip. This is standard wear and tear.

However, if your GenieGrips® Mats have excessive tearing and damage to the rubber and/or metal components as in the above images please contact your GenieGrips® representative to order a replacement set.



STEP 5:

Storage of Mats

Fold Mats in half and store away neatly on forklift to ensure GenieGrips® are easily accessible at all times.



IMPORTANT: Clearance

"When picking up goods, there must be sufficient clearance above Mats when installed (30mm recommended) to ensure they do not scrape or buckle by forcing against load

– see picture on left.