


Bulletin Number 608
Price \$10.00

The



Conveyor Book*

"This book will help you to talk
about HYTROL CONVEYORS . . .
and help you SELL THEM!"

HYTROL CONVEYOR CO., INC.
JONESBORO, ARKANSAS
© COPYRIGHT 2008-HYTROL CONVEYOR CO., INC.



TABLE OF CONTENTS


	PAGE
What is a Conveyor	3
What is a Belt Conveyor.	4
What is a Bearing	5
How the Drive Pulley Does the Work	6
What is a Sprocket	7
How the Drive Pulley is Driven	8-15
The Conveyor Drive	10
Tail Pulley	11
The Conveyor Belt	12-14
How to Get More Belt Take-Up	15
How Conveyors are Made to do a Better Job	16-23
Belt Speed.	16
Drive Pulley Crowned and Lagged	17
Conveyor Drive Location.	18
The Snub Idler	19
How to Steer the Belt.	20
Power Feeder	21
Center Drive	22
Roller Bed Conveyors	23
What is a Gravity Conveyor	24-26
Wheel Conveyors	27-38
Roller Conveyors.	29-30
Move These on Wheel Conveyors.	31
Move These on Roller Conveyors	32
How Gravity Conveyors are Set Up	33-34
Flow System	35

WHAT IS A CONVEYOR?

A conveyor moves material.


A conveyor moves cardboard boxes, wood boxes, metal boxes and plastic boxes.

A conveyor can move material.



This is called a **GRAVITY CONVEYOR**.

A conveyor can do more. it can move boxes **UP** against gravity . . . **DOWN** . . . or **HORIZONTAL** on a moving belt.




The belt is moved by electric power.

This is called a **BELT CONVEYOR**.

WHAT IS A BELT CONVEYOR?

It is a machine with a moving BELT.

The machine is made with these parts:



This is a conveyor bed.

It comes in many sizes-many lengths-many widths.


A PULLEY

A pulley is like an IRON PIPE.

Pulleys are put on each end of the bed.

The pulleys are as wide as the bed.

Each pulley has a steel shaft through it.




The shaft turns on a bearing . . . and the pulley turns with the shaft.

WHAT IS A BEARING?


When two pieces of steel touch each other, they cannot turn easily without bearings.

Bearings use little steel balls to keep the pulley shaft and the conveyor bed from rubbing together.

BALL BEARING



Now the shaft can turn easily.




Pulley "A" is the drive pulley.

Pulley "B" is the tail pulley.

The drive pulley is usually larger because it does the work.

HOW THE DRIVE PULLEY DOES THE WORK


The drive pulley is turned (driven) by a motor.
A sprocket is put on the drive pulley shaft.



A sprocket is put on the motor.


WHAT IS A SPROCKET?

A sprocket is a metal "wheel" with "teeth" on the outside.



HOW THE DRIVE PULLEY IS "DRIVEN"

A chain is put around the Drive Pulley Sprocket and the Motor Sprocket.




The chain moves when the motor is started.
The chain turns the drive pulley.

BUT! . . .

Because a motor turns very fast (1750 times per minute) . . .

A SPEED REDUCER must also be used.

The SPEED REDUCER is put between the motor and drive pulley.




...The motor is connected to the reducer with a V-Belt (like the fan belt in your car) or a "C" Face Coupling.

The reducer is connected to the drive pulley with a chain . . . Now the Drive Pulley turns slower.

All these parts (the motor, the speed reducer, and the drive pulley) are called:

THE CONVEYOR DRIVE


They must be put together to take up as little space as possible — so




The motor and reducer and put under and within the conveyor bed.

But what about the

TAIL PULLEY?




It is located at the tail end of the conveyor.



It turns FREELY . . . Like a dog's tail.

Now a "belt" can be put around the pulleys.


THE CONVEYOR "BELT"



The Drive Pulley turns and moves the belt around
... and around ... and around.

BUT...

... it is dangerous to have the belt hang down under the conveyor bed - So small rollers are put into the Conveyor Bed to hold up the belt.




These turn freely -- and just idle.
They are called "Return Idlers".

SOME TYPES OF BELTS STRETCH MORE THAN OTHERS

What to do?

1. Move the tail pulley! It can be moved to “take up” the belt stretch.



There are “take-up” screws on both sides of the conveyor.


Move these screws out slowly.

Move them the same amount on both sides!

This keeps the belt tight.

2. What do you do when the take-up screws are still all the way out - and the belt still stretches?

LONGER CONVEYORS ARE PROVIDED WITH ONE OR MORE SHORT PIECES OF BELT ADDED. THIS SHORT PIECE OF BELT IS CALLED A "DUTCHMAN"




REMOVE THE SHORT PIECE(S) OF BELT.

Now you can start the "take-up" procedure all over again.

NOTE: If a "Dutchman" was not provided, you may need to add an UNDERSIDE TAKE-UP to your conveyor.

HOW TO GET MORE BELT TAKE-UP

There is more belt stretch on a long, long conveyor than the regular take-up and the dutchman will give. So an "Underside Take-Up" should be used.



WHEN TO USE UNDERSIDE TAKE-UP

ON CONVEYORS 60 FT. LONG (OR MORE)

NOTE: AN UNDERSIDE TAKE-UP is often used when the overall length of the conveyor cannot be changed and the TAIL PULLEY "take-up" cannot be used.

HOW CONVEYORS ARE MADE TO DO A BETTER JOB

1. A CONVEYOR BELT MOVES AT A SPEED OF 65 FEET PER MINUTE (FPM).


This is the best speed to move objects from one place to another.



A person can walk about 4 miles per hour. If they were carrying a box they would walk much slower. Conveyors move boxes at about the same speed as a person carrying them. This is about 65 feet per minute (or about $\frac{3}{4}$ of a mile per hour).


2. THE DRIVE PULLEY IS CROWNED AND LAGGED

- A.** The drive pulley is larger in the center than the ends. This helps keep the belt in the center. This is called a "Crown."




- B.** The drive pulley is completely covered with vulcanized rubber. It is called "lagging." This keeps the pulley from slipping under the belt.

3. THE CONVEYOR DRIVE IS NORMALLY LOCATED AT THE END TO WHICH THE BELT MOVES.



NOTE: if the belt movement were reversed, the pulley would be pushing the belt. When the conveyor was fully loaded or when the belt stretched, the pulley could turn and not move the belt.

4. THE SNUB IDLER



The Snub Idler is closer to the drive pulley.

It makes the belt hug more of the drive pulley surface.


the Snub Idler is **ADJUSTABLE**.

It is **ADJUSTABLE ON BOTH SIDES** of the conveyor.

(Each side of the snub idler can be adjusted independently.)

Reason - The Snub Idler is used to steer the belt.

5. HOW TO "STEER" THE BELT




- When belt runs forward and if it moves toward side "A" - move return idler nearest tail pulley on side "Y" toward "B" • If belt moves toward side "B" - move return idler on side "X" toward "A".
- When belt runs in reverse and if it moves toward side "A" - move snub idler on side "X" toward "A"
 - If belt moves toward side "B" - move snub idler on side "Y" toward "B".

IMPORTANT: Move snub idler or return idler only 1/16 in. at a time. Then wait a few minutes to see if belt moves back to center. Only small adjustments are usually necessary.


6. POWERED FEEDER

(Used with incline Belt Conveyors)

A. When boxes move from gravity conveyor to inclined belt conveyor, the box usually stops or "hangs up." The box will not transfer.



B. With a Power Feeder, transfer of the box is positive.




The Power Feeder is driven from the main conveyor by a short chain connection.

7. CENTER DRIVE

(Used with Horizontal Belt Conveyors)

A. When belt movement is REVERSIBLE
(on conveyors 40 ft. long or more)

B. When overall length of conveyor cannot change
(belt take-up by tail pulley increases conveyor length)



CENTER DRIVE SHOULD BE USED


Because:

A. Drive pulley now "pulls" belt in either direction

B. Take-up pulley can now be used to take-up belt

8. ROLLER BED CONVEYORS

When heavy total loads must be moved, it is best to use a conveyor bed with rollers (instead of regular conveyor bed).



This is a Roller Bed belt conveyor

Heavy total loads can be moved without using large motors when a **ROLLER BED** belt conveyor is used.

BELT CONVEYORS are often used with
GRAVITY CONVEYORS

You should know about
GRAVITY CONVEYORS, TOO!


WHAT IS A GRAVITY CONVEYOR?

A gravity conveyor moves objects without motor power.




BY GRAVITY

To help objects move "easier" . . . and with as little slant or slope as possible -




WHEELS or...



ROLLERS...


ARE USED

The **WHEELS** or **ROLLERS** are put into channel frames held together with "bed spacers."




Different widths can be made. Frames can be either **STEEL** or **ALUMINUM**.

WHEEL CONVEYORS




Wheels are put on axles. Aluminum spacer tubes are put on the axle between the wheels. This keeps wheels from moving from side to side on the axle.



In the drawing above, the axles are on 3 in. centers (also available in 1-1/2 in. centers). The number of wheels on each axle can vary. This determines the number of wheels per foot on the conveyor.


BUT. . .

There should always be a minimum of 10 wheels under a box.




This helps you decide the number of wheels per foot to order.


ROLLER CONVEYORS



Rollers have their own axles. Most axles are **SPRING LOADED**. This means . . .




SPRING . . . The axle can be moved to one side.




Rollers can be easily removed or replaced in Conveyor Channel frame. The spring also keeps the roller in place.


The rollers are put in the frame as close together -



or as far apart as necessary . . . **BUT** there should always be **THREE (3)** rollers under the box.



LESS THAN 3 ROLLERS . . . box tumbles.









BEST - 3 ROLLERS UNDER BOX AT ALL TIMES!

This determines the **ROLLER CENTERS** to order.

MOVE THESE ON WHEEL CONVEYORS

Any items with a smooth, flat bottom. These items can be wider than the conveyor. 6 in. over on each side is not too much. Extra wide items such as plywood can be moved, but should be centered carefully.












Tote boxes will not move easily.



Use as many wheels as possible for best results.



MOVE THESE ON ROLLER CONVEYORS.

Any items with an uneven or open bottom, or with a rim on the bottom. These items should never be bigger around than the rollers are long.




HOW GRAVITY CONVEYORS ARE SET UP

1. All sections have couplings.




Sections can then be used together by coupling them to each other.

2. PORTABLE SET-UP USE TRIPOD STANDS




Always use one more stand than the number of conveyor sections (3 sections use 4 stands.)

3. PERMANENT SET-UP USE STATIONARY SUPPORTS



Always use one more support than the number of conveyor sections (3 sections use 4 supports.)

POWERED AND GRAVITY CONVEYORS CAN BE USED TOGETHER!



This is called a "Flow System".

For more detailed information on any part of this booklet, contact:

**HYTROL CONVEYOR CO. INC.,
2020 Hytrol Street
Jonesboro AR 72401**

**Visit our web site at:
www.hytrol.com**



HYTROL CONVEYOR COMPANY, INC.

**2020 Hytrol Street
Jonesboro AR 72401**

(870) 935-3700

www.hytrol.com

**EFFECTIVE SEPTEMBER, 2008
PRINTED BY MASTER PRINT GROUP**